

Engage: Toggles effect on/off (Bypass) Infinity Switch (∞): Toggles modulation crosstalk (no effect in bypass) Infinity Knob (∞): adjusts level of ring-mod crosstalk Anomaly knob: Sets frequency of the carrier oscillator Lux Mode: Analog carrier modulates the input signal Aeterna Mode: Input signal modulates doubled carrier frequency Mixer section: Independent controls for effected and dry signal by Discomfort Designs